


## Reading out the software (firmware) version

1. Switch ON.  
(Hold Power 3 seconds)

2. Push 'settings'

3. Select 'information'  
4. Push <OK>  
5. Read out version




## SOFTWARE UPGRADE


### Preparing the software (firmware)

The software comes in a .zip file. The name corresponds with the version of the software. For example: *V5\_00\_13.zip*.

After extracting



1. Extract the zip file




2. Copy or move the folder "42-I+CPU" to the USB drive.

### Updating the software (firmware)

1. Disconnect the mains supply



2. Connect the USB drive.



3. Connect the mains supply



4. The following messages appear

Bootloader version V1.02.02

-USB stick found  
starting upgrade

-Checking CRC

-Copying file  
-Loading application

-Checking CRC

-Please remove USB stick  
to start application

5. Disconnect the USB drive.

